



HOW TO mix products in the spray tank



IMPORTANT:
DO NOT use more than 4 products in tank.



IMPORTANT:
ALWAYS read the product labels.



01 START WITH:

Fill spray tank up to 50%.

50%

Mix water in tank.

02 CORRECT WATER QUALITY:

Read label to see product specific, desired pH.

ADD: Ammonium Sulphate, buffers and other products.
No stickers!

03 DRY FORMULATIONS:

ADD: Mix Wettable Granular (WG) with water before adding to tank.

04 DRY FORMULATIONS:

ADD: Mix water-soluble bags (WP) with water before adding to tank.

05 SUSPENSION CONCENTRATE:

ADD: Suspension Concentrate (SC) to tank

06 EMULSIFIABLE CONCENTRATE:

ADD: Mix Emulsifiable Concentrate (EC) with water before adding to tank.

07 WATER-SOLUBLE LIQUIDS:

ADD: Water-Soluble Liquids (SL) to tank.

08 OTHER ADJUVANTS:

ADD: Stickers, Wetters and oil-containing Adjuvants to tank, see product label.

09 FOLIAR FEED SUSPENSION:

ADD: Foliar Feed Suspension (WS) to tank.

10 END WITH:

Fill spray tank until full.

100%

Mix tank mixture.